

ASSEMBLY INSTRUCTIONS

ACME Furniture

Double bed frame

BEFORE YOU START, HERE IS SOME HELPFUL ADVICE

We suggest you spend a short time reading through this leaflet and follow the simple step-by-step assembly instructions.

Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.

Assemble this product on a flat surface.

Assemble all parts loosely before tightening any bolts.

Discard all extra fittings and keep fittings out of reach of children.

To clean, wipe clean with a damp cloth.

Retain Assembly Instruction for future reference.

PARTS AND FITTINGS LIST

PARTS LIST			
CODE	DESCRIPTION	QTE.	
1	HEADBOARD PANEL	4	
2	HEADBOARD POST (LEFT)	1	
3	HEADBOARD POST (RIGHT)	1	
4	FOOTBOARD PANEL	1	
5	FOOTBOARD POST (LEFT)	1	
6	FOOTBOARD POST (RIGHT)	1	
7	SIDE RAIL (LEFT)	2	
8	SIDE RAIL (RIGHT)	2	
9	SIDE RAIL CENTER LEG	2	
10	CENTER SUPPORT	2	
11	SUPPORT LEG	4	
12	SLATS	2 SET	
FITTINGS LIST			

CODE DESCRIPTION QTE A Image: Graph of the state of	FITTINGS LIST				
B Image: Constraint of the second	CODE		DESCRIPTION	QTE.	
C Image: Constraint of the state of the sta	Α		JCBC M6 x 110mm	10	
D BARREL NUT M6 x 15mm 18 E JCN M6 x 15mm 8 F O WOOD DOWEL M10 x 40mm 4 G CSK SCREW M4 x 25mm 36 H ALLEN KEY M4 2 I WOOD DOWEL M8 x 30mm 20	В		JCBC M6 x 70mm	8	
E Image: Constraint of the state of the sta	С	-0	JCBC M6 x 30mm	16	
F WOOD DOWEL M10 x 40mm 4 G CSK SCREW M4 x 25mm 36 H ALLEN KEY M4 2 I WOOD DOWEL M8 x 30mm 20	D		BARREL NUT M6 x 15mm	18	
G CSK SCREW M4 x 25mm 36 H ALLEN KEY M4 2 I WOOD DOWEL M8 x 30mm 20	E		JCN M6 x 15mm	8	
H ALLEN KEY M4 2 I Image: Comparison of the system of the sy	F		WOOD DOWEL M10 x 40mm	4	
I WOOD DOWEL M8 x 30mm 20	G	<uun td="" €<=""><td>CSK SCREW M4 x 25mm</td><td>36</td></uun>	CSK SCREW M4 x 25mm	36	
	Н		ALLEN KEY M4	2	
J WOOD DOWEL M10 x 25mm 4	I		WOOD DOWEL M8 x 30mm	20	
	J		WOOD DOWEL M10 x 25mm	4	
K O WOOD BUTTON 18	К	9	WOOD BUTTON	18	



mm 10 20 30 40 50	60 70 80 90 100
-------------------	-----------------





