ASSEMBLY INSTRUCTION MODEL: #66922 SIDE CHAIR

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small part wich may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with part list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

*** Do not fully tighten screws untill fully assembled ***

| | *** Do | not fully tighten s | screws unti | ill fully ass | sembled *** | | | |
|------------------------|--------------|---------------------|-------------|---------------|-------------------------------------|--------|--------|--|
| PARTS LIST | | | | HARDWARE LIST | | | | |
| NO | DESCRIPTION | SKETCH | QTY | NO | DESCRIPTION | SKETCH | QTY | |
| A | BACK FRAME | | 1 PC | 1 | ALLEN WRENCH (L57 * 4MM) BOLT | | 1 PC | |
| В | SEAT CUSHION | | 1 PC | 2 | (Ø5/16 " * 2-1/4 ") BOLT | | 4 PCS | |
| | W/FRAME | | | 3 | (Ø5/16 " * 3-1/4 ") | | 4 PCS | |
| C | FRONT LEG | | 2 PCS | 4 | BOLT (Ø5/16 " * 1-3/4 ") | | 2 PCS | |
| | | | | 5 | LOCK WASHER (Ø5/16"*13*1.2) | Q | 10 PCS | |
| | | | | 6 | FLAT WASHER (Ø5/16"*19*1.8) | | 10 PCS | |
| STEP 1 STEP 2 STEP 2 | | | | | | | | |
| Made in Viet Nam | | | | | COMPLETED | | | |