
ASSEMBLY INSTRUCTION FOR ACME FURNITURE MODEL# 91880 & 91885 TV STAND

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Separate, identify, and count all parts and metal hardware. Compare with parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of the part(s) needed.

*** Do not fully tighten screws until fully assembled ***

COMPONENT PARTS			
DECERPTION		PART NAME	Q'TY(PCS)
1	Front Frame		1pc
2	Back Frame		1рс
3	Тор		1pc
4	Side Frame		2pcs
5	Vertical Panel		2pcs
6	Middle Shelf		1рс
7	Bottom Shelf		1рс
8	Side Shelf		2pcs

HARDWARE REQUIRED:			
Α		Bolt 3/16"x3/8" - 8pcs	
В		Bolt 1/4"x5/8" - 8pcs	
С		Bolt 1/4"x3/4" - 8pcs	
D		Allen Wrench M4 - 1pc	



Attention:

***Mattreses not included.

***Some number parts listed on the instruction sheet may not be in parts bag as they may already be assemble. Carefully check parts and packing materials prior to odering replacements.

