ASSEMBLY INSTRUCTION FOR ACME FURNITURE MODEL # 92034 COMPUTER DESK

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local fumiture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needde.

*** Do not fully tighten screws until fully assembled ***

COMPONENT PARTS		
DESCRIPTION	PART NAME	Q'TY(PCS)
1	Side panel	2 PCS
2	Back plate	1 PC
3	Panel	1 PC
4	Drawer	1 PC

HARDWARES REQUIRED

A L-ALLEN KEY Ø 4mm − 1 PC

B Bolt Ø **1/4″x1″** − 10 PCS

C S Lock Washer Ø 1/4" - 10 PCS



Attention:

*** Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled.

Carefully check parts and packing materials prior to odering replacements.





