






ASSEMBLY INSTRUCTION FOR ACME FURNITURE

MODEL#52660 SOFA

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

***** Do not fully tighten screws until fully assembled *****

COMPONENT PARTS			
DESCRIPTION	DRAWING	PART NAME	Q'TY(PCS)
①		SOFA	1
②		WOODEN LEG	4
③		CENTER SUPPORT	1
④		PLASTIC WASHER	1
⑤		BACK CUSHION	2

HARDWARES REQUIRED

Ⓐ  BOLT 14X22mm — 16PCS

Ⓑ  ALLEN KEY — 1PC


Attention:

*** Mattresses not included.


*** Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and packing materials prior to ordering replacements.

Please follow the drawings below to assemble the model.

Step.1



Step.2



Step.3

